






Parts List



Intel Installation Guide




AMD Installation Guide




Installation Guide


1




2




3




4




5



Intel



or AMD



MB SYNC Installation Guide

⚠ CAUTION

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

